

Connection

- Line input - connect your MP3 or CD player to this input
- Line output - connect your external amplifier to this output
- Headphone - connect your headphone to this headphone output



- When the supplied USB cable is connected to any 5V charger, charging will start. When connected to PC, DAC mode will be activated. (See later section)
- Charging indicator - red LED when charging and turn off after fully charged

Operation

- Power - press and hold this button to turn on/off NIK58-DAC - single press will toggle between USB and line in mode
- Volume button - press this button to change the volume level
- Reset button - using a pin, press and hold this button to reset

USB connection

When connect your NIK58-DAC to your PC with the supplied USB cable, you will be able to see the screen shown below (if using Win 7):



Wait for a few more seconds, below screen will be seen:



Now you can hear music of your PC using NIK 58-DAC and control the music playback using the supplied remote control



- Use these button to control your PC music playback
- Use this button to toggle between USB and line in mode
- Use this button to power OFF the NIK58-DAC
- Use this button to mute